



Install the macOS 11.x Ethernet driver for the original CalDigit USB-C Dock


1. Download and unzip the driver from <https://downloads.caldigit.com>
2. Click on driver installer package




3. Follow the instructions to install the driver









4. At the end of the installation, it will notify you to reboot OS and go to either Launchpad or your macOS' Application folder to run an application called "Gx3\_USB\_Ethernet\_APP"




5. Once you reboot your OS, go to Application folder and run an application called “Gx3\_USB\_Ethernet\_APP”




6. Follow the instruction to active the driver by clicking on “Activate” button.




7. A popup message showing “System Extension Blocked” will appear. Click on “Open Security Preferences”



8. Go to Security & Privacy to allow “Gx3\_USB\_Ethernet\_App” to run.



9. You may see a popup window showing below. Please check “Gx3\_USB\_Ethernet\_App” then click on “OK” button. The restart your computer.



10. If everything is installed correctly and if the Ethernet cable is plugged in to your USB-C Dock, you should see the network interface (with a green dot) associated with your USB-C Dock under Network preference.

